

4-IN-1 STYLUS PEN

FOR PDAs AND HANDHELDS

The Belkin 4-in-1 STYLUS PEN adds versatility to your PDA. It includes a touch screensensitive stylus for navigation of your PDA, red and black ball-point pens, and a mechanical pen with eraser.

How to use your 4-in-1 PDA Stylus Pen

- 1. The 4-1 Stylus Pen contains black and red ink ballpoint pens, a 0.5mm mechanical pencil, and a PDA stylus.
- 2. To use the instrument you want, depress the top button. Under the button cover is an eraser. Simply pull the cap off to use.
- 3. To retract a pen, press the release button.
- 4. Located on the barrel of the pen are markings identifying the pens and pencil inside. BLACK - Black ink ballpoint pen, RED - Red ink ballpoint pen, 0.5 - 0.5mm mechanical pencil, STYLUS - PDA stylus.



How to Select and Use the Pens/Pencil

- 1. Locate the instrument you want using the markings on the barrel of the pen.
- 2. Hold the desired marking so that it is facing up.
- 3. Depress the top button to engage the selected instrument

Replacing the Ballpoint Pens

- Unscrew and remove the tip from the base of the pen.
- 2. With the pens/pencil exposed, locate the pen to replace; remove it by pulling it out of its barrel.
- 3. Insert the refill pen firmly into the open barrel; replace the pen tip.

Belkin Components

310.898-1100 · Compton · CA · 90220-5221 · USA Designed in the USA Belkin Components, Ltd. +44(0) 1604678300 · Round Spinney · Northhampton · NN3 8RX · United Kingdom

Made in Taiwan

© 2001 Belkin Components. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.

Feeding the Pencil Lead

- 1. Select the mechanical pencil instrument.
- 2. Hold the pen tip down.
- 3. Depress and release the top button in a pumping motion until the lead is the desired length.

Refilling the Mechanical Pencil

- 1. Unscrew and remove the tip from the base of the pen.
- 2. With the pens/pencil exposed, locate the pencil; remove it by pulling it out of its barrel.
- 3. Add o.5mm pencil leads to the open barrel; put the pencil tube back into place.
- 4. Replace the pen tip; follow steps on "Feeding Pencil Lead".





F8E708

P96343